

**Installation of CombiBox Pits
in existing Apron
at
Lyon Saint Exupéry (FLLL-LYS)
Sept 2005.**





Pits are shipped on steel frames for easy handling.



**Unused conduits are sealed.
Note leveling bolts.**



Excavation (more room around pit advisable) and concrete slab in bottom with drop down drainage (here thanks to absorbent soil).



Positioning of Pit using slings around top angles.



Accurate positioning and levelling using levelling bolts.



Last minute change in conduit size may be adapted and connection sealed with PU foam.



Non compulsory inside check; depends on local workers sense of humor.



**Pour light concrete / fluid mortar around the pit to maintain properly.
Do not pour more than about 25cm / 10 inches from the bottom of the
pit to prevent it floating.**

**Next day, continue backfilling and compacting or pour concrete around
the pit up to grade.**